accenture avanade Microsoft



# Gum Optimization YRV-GNV Mars Wrigley

Silvia Catalán

February 2023

## **GUM OPTIMIZATION**


## **USING VISION SYSTEM TO IMPROVE GUM QUALITY**

## THE CHALLENGES ADDRESSED

Gum defects or gum measurements being out of thresholds are detected very late in the manufacturing process. This translates into:

- Production line stoppages
- Waste of kgs of material produced
- Delays in production schedule, amongst other disruptions.

By leveraging data and analytics capabilities and improving the visibility of gum processing we can mitigate these challenges and reduce losses



## **POTENTIAL USE CASES**

## WE IDENTIFIED THREE POTENTIAL USE CASES THAT COULD BE APPLICABLE TO YORKVILLE AND GAINESVILLE SITES

1 BATCH MANAGEMENT

Automated batch reporting system for visibility of unknown issues resulting in higher quality and more consistent gum.

Out of scope

2 GUM MEASUREMENTS

Use visual inspection to measure circular LAND settings that eliminates operator subjectivity **to improve the regularity of gum measurements**, **score depths** and **reduce short stops downstream** in the wrapping process.


YRV + GNV

3 GUM DEFECTS

Use visual inspection to **identify holes/spots & trim abnormalities** to improve gum quality and **reduce short stops** further downstream in the wrapping process.

GNV

**Objective:** Accurate way to measure circular LAND settings across multiple lines that eliminates subjectivity to improve the regularity of gum measurements and reduce short stops further down in the wrapping process.



1 The laser profiler continuously measures the width of the gum sticks as well as circular land score depth. The camera is placed after the Circular Scoring Rollers above and centre of the cards.

Scanning Area = 39mm (2 Circular Land Scores)

Width: Distance between score lines Land score Depth: Roller balance and knife + scraper settings The line scanner is placed above and perpendicular to the moving belt. The camera's shutter is synchronized to the belt movement by using a rotational encoder. When a signal from the encoder is received, the camera takes a picture.

A strobe light illuminates the back of the cards.



**Objective:** Accurate way to measure circular LAND settings across multiple lines that eliminates subjectivity to improve the regularity of gum measurements and reduce short stops further down in the wrapping process.

## **Cold Scoring line - YRV**

#### **Line Scanner located after rollers**



#### **Laser Profiler located in between rollers**



## Hardware used


#### **Line Scan Camera Set-up**

- Keyence CA-HL02MX
- · Captures the length, output the measurements
- The resolution of the scan line is 2000px. The
  resolution in the direction perpendicular to the scan
  line depends on the resolution and setting of the
  digital encoder. The settings will be adjusted so that
  the final resolution is identical to the scan line
  resolution.
- The size of the FoV in the direction parallel to the scan line is 0.7" – 1.41"; in the direction perpendicular to the scan line it can be unlimited

### **Laser Profiler Set-up**

- · Laser profiler: LJ-X8080
- The width of the scanning area is 39mm (1.54") which allows a scan of ~2 circular land scores at a time.
   Captures cross land score.
- A laser profiler provides the circular land score and width of a gum stick
- Profiler controller and Signal converter will be used to transfer data

- Each card consists of 26 gum sticks
- x = length of gum stick (2.86 in)
- y = width of gum stick (0.74 in)



Moving belt direction

Hardware	Use
Line Scanning System	Image scans measures <b>length</b> of the gum stick.
2D Laser Profiler	Measurement of the Circular land scores and width of the gum stick
Light source	Light source (back)

## 2

## **GUM MEASUREMENTS**

## **Analytics Solution**

### **Descriptive analysis:**


- Display measurement results and report if they are within thresholds
- Send alert via Teams to operator when values are out of threshold

## **Predictive analysis:**

- · Check the **tendency** of the values
- · Predict when the values will be out of threshold
- · Send alert via Teams to operator when necessary

#### Visualization:

- Users are able to see if the length, width and land score depth of the gum stick is within thresholds
  - · Real-time: across the past 30 minute time period
  - Historically: measurements are displayed for the production runs of the last 2 weeks
- Historical KPIs per production run are also available to track production success.



## **Architecture Overview**


The ETL is triggered by an event (a new payload arriving)

#### · Real-time analysis:

- Cleaning and analysis of the data, calculates if measurements are within or outside thresholds
- If they are outside thresholds and alert is sent to Teams channel
- The information is then ingested in powerBI

#### · Historical KPI calculation:

- Every 2 hours and also when a production run is finished a process is launched to calculate main KPIs (number of errors, operator responses...)
- This information is stored in sql tables
- · These tables are ingested in powerBI



## GUM MEASUREMENTS SCALED VALUE CASE

% OF GLOBAL **REDUCTION IN REDUCTION IN SCALING SHORT STOPS PRODUCTION WASTE OPPORTUNITY** Assumption of reducing waste by 48% TBD **YRV** 13% \$171k **TBC GNV** 42% \$530k **TBC** \$530k **GNZ** 9% \$118k **TBC YNG** 15% \$186k \$186k **TBC** DOE 14% \$177k **TBC Scaled Opportunity:** \$1.2m **TBC** \$1.2m+


# **GUM OPTIMIZATION – WHAT'S NEXT? GNV MVP PLANNING**

#### 1-GUM MEASUREMENTS DEPLOYMENT:

Refactor solution and go live in 4 weeks

#### 2- GUM DEFECTS DETECTION: (10 weeks)

- Camera takes synchronized pictures of every gum sheet in the conveyor belt.
- An accurate computer vision model is developed to detect defects on real-time
- Alerts are sent via teams so that operators can take corrective actions



## Types of defects: holes, rigged edges, ingredient spots

Large amount of pictures are needed to develop a CV model



accenture

Thank you!

谢谢